



American Party Place  
4522 S Tacoma Way, Tacoma, WA 98409  
253-473-3300  
[www.americanpartyplace.com](http://www.americanpartyplace.com)

# Coffee Maker

## Do not:

- Immerse the coffee pot in water

## To Operate:

1. Fill coffee pot with cold water to desired amount
2. Add coffee to basket (see equivalent below)
3. Plug coffee pot into electrical outlet

## **Note:**

- When coffee has finished brewing, remove basket. The coffee pot will keep coffee hot
- Takes approx. ½ hour to brew 30-60 cups of coffee; approx. 1 hour for 90-100 cups of coffee
- For every 2 cups of coffee, approx. 30 cups of coffee will be brewed (1 pound of coffee = 4 ¾ cups of ground coffee)

## Cleaning Instructions:

1. Rinse our coffee pot and basket before returning

**\*A \$5.00 cleaning charge will apply if coffee maker is not returned cleaned\***