

Gas Griddle Instructions

Gas grills are designed for **OUTDOOR USE ONLY!!!**

1. Remove the griddle cleaning brush that is located on top of flat top.
2. Make sure all control knobs (located on the right of the griddle) are placed in the closed position (pointing toward you)
3. Connect the regulator to the propane tank
4. Slowly and completely open the main cylinder valve (located on top of propane tank). Turn the control knobs on the griddle used to “open” to a 45 degree angle. **WAIT 10-15 SECONDS BEFORE LIGHTING!**
5. Hold a lit butane gun to the right of the closest tube located underneath the flat top part of the griddle. All tubes should light instantly.
6. Turn control knobs to desired temperature.
7. When finished, close the control knobs, close the main cylinder, and disconnect the propane cylinder

Clean up

We recommend that you clean the griddle *while it is still hot* with the grill brush that we have provided you. It makes it easier to remove food and sauce from griddle when it is still warm.

*****IF THE GRIDDLE DOES NOT COME BACK
SCRUBBED AND CLEANED YOU WILL
FORFEIT THE \$75.00 CLEANING DEPOSIT*****

Errors and Corrections for if Griddle does not Light

- Completely shut off griddle and propane tank. Redo Step 4 and 5. There is a trip valve located in the propane tank that automatically shuts off the flow of the propane if opened to fast.
- Remove Griddle from any windy areas. Relight! Some grills tend to have a smaller flame when located in a windy area.

